

## Repair Parts

Item	Description	Part No.
<b>1</b>	Air tube with welded flange for specific appliance	Consult Factory
<b>2</b>	Motor, 1/6 hp, 3450 rpm, Carlin PSC	98022
<b>3</b>	Electrode wire, set of 2, 7" nominal, approx. 8-1/2" oal	82776
<b>4</b>	Nozzle line/adaptor assembly, 7" nominal, approx. 8-3/4" oal	56861
<b>5</b>	Ignitor, Carlin electronic	45000
<b>7</b>	Fuel unit, std. single stage, Suntec A2VA-3006	98750
<b>9</b>	Oil line, 3/16 od, std. fuel unit to nozzle line	34470
<b>10</b>	Coupling, for std. fuel units, approx. 2-3/8" oal	75564
<b>11</b>	Air band (EZ-1), with 100 PSIG scale	98055
<b>12</b>	Air shutter, blank (EZ-1) (EZ-LF)	97780
<b>13</b>	Head positioning slide bar kit	51593S
<b>14</b>	Combustion head assembly 7"	77966
<b>15</b>	Electrode bracket	23135
<b>16</b>	Bracket, nozzle line heater	64493
<b>17</b>	Nozzle line heater w/electrical disconnect (optional)	66787
<b>18</b>	E-ring for nozzle line (not shown)	50624
<b>19</b>	Thumb nut, nozzle line	62885
<b>20</b>	Gasket, ignitor	51586
<b>21</b>	Cad cell	4002400A
<b>22</b>	Ignitor terminal kit, (2 terminals & nuts)	24463
<b>23</b>	Ignitor hold-down tab, two required	44842
<b>24</b>	Junction box, 4"x4", w/grommet and lockwasher	44586
<b>25</b>	Blower wheel, 5-1/16d x 2w	77933
<b>26</b>	Primary control (consult factory for other controls)	70200
<b>28</b>	Gasket, mounting flange	Consult Factory
<b>31</b>	Retention Ring	77438S
<b>32</b>	Nozzle (consult Setup Guide)	-
<b>34</b>	Plug-in wire harness (not shown)	Consult Factory
<b>35</b>	Elbow, 3/16 flare x 1/8 NPT	29926
<b>40</b>	Access cover w/deflector (EZ-1)	99282A

# Repair Parts (continued)

