


Repair Parts (continued)



Repair Parts

Item	Description	Part No.
1	Air tube with welded flange for specific appliance	Consult Factory
2	Motor, 1/6 hp, 3450 rpm, Carlin PSC	98022
3	Electrode wire, set of 2, 7" nominal, approx. 8-1/2" oal	82776
4	Nozzle line/adaptor assembly, 7" nominal, approx. 8-3/4" oal	56861
5	Ignitor, Carlin electronic	45000
7	Fuel unit, std. single stage, Suntec A2VA-3006B	98750
9	Oil line, 3/16 od, std. fuel unit to nozzle line	34470
10	Coupling, for std. fuel units, approx. 2-3/8" oal	75564
11	Air band with PSIG scale, 1 slot	98055
	Air band with PSIG scale, 2 slot	98087
	Air band with 100% scale, 2 slot	98101
12	Air shutter, blank (EZ 1) (EZ LF)	97780
13	Head positioning slide bar kit	51593S
14	Combustion head assembly 7"	77966
15	Electrode bracket	23135
16	Bracket, nozzle line heater	64493
17	Nozzle line heater w/electrical disconnect (optional)	66787
18	E-ring for nozzle line (not shown)	50624
19	Thumb nut, nozzle line	62885
20	Gasket, ignitor	51586
21	Cad cell	4002400A
22	Ignitor terminal kit, (2 terminals & nuts)	24463
23	Ignitor hold-down tab, two required	44842
24	Junction box, 4"x4", w/grommet and lockwasher	44586
25	Blower wheel, 5-1/16d x 2w	77933
26	Primary control (consult factory for other controls)	70200
28	Gasket, mounting flange	Consult Factory
31	Retention Ring	77438S
32	Nozzle (consult Setup Guide)	–
34	Plug-in wire harness (not shown)	Consult Factory
35	Elbow, 3/16 flare x 1/8 NPT	29926
40	Access cover w/deflector (EZ 1)	99282A